

CORRECTLY RESTRINGING YOUR GUITAR

As simple as it may sound, proper string fitting is critical to the playability of your instrument. An incorrectly fitted string can slip and cause the instrument to go out of tune.

To fasten a string on the string post to prevent slipping, bring the string up the centre of the instrument to the post desired. Put string (A) through the hole or slot in the post at (B) to (C); around the upper side of the post (D), and under the string (A) at (B), back again around the string post (D). Now when you wind the string it will lock itself against the post.

